



FACE FIXING BRACKET

(recommended when fitting your blind to an outside recess)

- Fixing your blind to the wall or directly against the frame requires two screws for each bracket (A)
- Position the bracket against the surface at the point you want to hang your blind
- Using a pencil, mark through the two outer holes on each bracket
- Using suitable fixings for the surface, screw the bracket into the wall (you may need wall plugs and a drill for this bit!)






Top fixing bracket (B)

TOP FIXING BRACKET

(recommended when fitting your blind to an inside recess and bay windows)

- Fixing your blind to the surface above it (e.g. the top of your window recess or ceiling) requires one screw for each bracket (B)
- Position the bracket against the surface at the point you want to hang your blind
- Using a pencil, mark through the hole on each bracket
- Using suitable fixings for the surface, screw the bracket into the wall (you may need wall plugs and a drill for this bit!)




ATTACHING THE BLIND

- To attach the blind to the brackets, hold it at a slight angle and push the front lip of the rail onto the plastic lip of the bracket
- Gently push the blind towards the back of the bracket and straighten, until it locks in place
- To remove the rail, simply push it towards the back of the bracket and twist the rail downwards at the back. This will release it from the hooks on the bracket

CHILD SAFETY

- The 'P' clip provided must be fixed at the maximum distance possible to prevent the chain becoming slack
- Slip the clip onto the chain and place against the wall.
 Mark the position of the hole with a pencil, and attach to the wall using suitable fixings
- To avoid strangulation and entanglement, keep chains out of reach of young children. This is in line with the safety standards recommended by the British Blind and Shutter Association (BBSA), which is part of the 'Make it Safe' campaign. Visit makeitsafe.org.uk to find out more





P-clip

NEED HELP FITTING YOUR BLINDS?

Give our Chatterboxes a buzz on 0203 141 8300 or pop an email to awake@loaf.com